

HAGS®


Spiral




CC




1	SW82271	1 x	513 x 609 x 628mm	22.65 kg
2	SW82272	1 x	Ø1270 x 717mm	50.13 kg
3	8008451	6 x	ISO7380-1-M10x20-10.9	0.019 kg
4	8005499	1 x	140 x 35	0.00 kg








28/03/24























HAGS* © Playpower inc hags@hags.com www.hags.com













HAGS°

MASW81648


28/03/24









B











"play smart" rules

Do not play on broken or damaged equipment. Report it.
 Do not play without adequate safets surfacing below and around equipment.
 No helmets, necklaces or drawstring should be worn while on equipment.

 ✓ No helmets, necklaces or drawstrus should be worn while on equipment.
 ✓ Be careful of hot paly surfaces an always wear shoes while playing.
 ✓ Do not play tag or run on playgrot equipment and do not jump off of equipment.

 ✓ Watch your head! Do not run under bridges, decks, stairs, or other equipment.
 ✓ Be careful when equipment is wet.

✓ Be careful when equipment is wet. Do not play on snowy or icy equipmen
✓ Do not climb on roofs, railings, or posts, or on top of crawl through tube slides.

✓ Slide sitting down, feet first, and at a time. Do not slide up chutes or tubes.

Adults – do not slide with a child on your lap. It can injure your child's legs / Before letting go of overhead bars, hang down still, bend your knees a little and drop straight down with both feet. / Swing sitting down and do not jump out while swinging. Do not twist chains

A MARAUNIC

Playground equipment installed over hard surfaces such as concrete, asphalt or packed earth may result in serious injury or death from alls. Make sure that appropriate safely surfacing is present, before allowing children to play.

MARNING

Children have strangled and died while their tidhes caught on slides and other playground equipment. Before allowing children to play, remove helmets, scarves, necklaces, hood cords, neck drawstrings, and mittens connected through the sleeves. Also, remove any foreign ropes, strings, or shoe laces that may be feet to equipment.


WARNING


All playground equipment and rubber surfacing may become hot enough to cause burns. Check for hot surfaces before allowing children to play. Children should wear appropriate shoes at all times

▲ WARNING


Playing tag or running on or under playground equipment can lead to serious injuries from falls, collisions, and head strikes. do not run on or under playground equipment. Pay attention while playing and be careful.













"play smart" rules

✓ Do not play on broken or damaged equipment. Report it.
✓ Do not play without adequate safet surfacing below and around equipment.
✓ No helmets, necklaces or drawstring should be worn while on equipment.

No helmets, necklaces or drawstrishould be worn while on equipment.
Be careful of hot paly surfaces an always wear shoes while playing.
Do not play tag or run on playgrou equipment and do not jump off of

✓ Watch your head! Do not run under bridges, decks, stairs, or other equipment.

Be careful when equipment is wet. Do not play on snowy or icy equipmen On ot climb on roofs, railings, or posts, or on top of crawl through tube slides.

✓ Slide sitting down, feet first, and or at a time. Do not slide up chutes or tubes.
✓ Adults – do not slide with a child o

your lap. It can injure your child's legar / Before letting go of overhead bars, hang down still, bend your knees a little and drop straight down with both feet. / Swing sitting down and do not jump out while swinging. Do not twist chains

A WARNING

Playground equipment installed over hard surfaces such as concrete, asphalt or packed earth may result in serious injury or death from alls. Make sure that appropriate safely surfacing is present, before allowing children to play.

WARNING

Children have strangled and died while their othes caught on sides and other playground squipment. Before allowing children to play, remove helmets, scarves, necklaces, hood cords, neck drawstrings, and mittens onnected through the sleeves. Also, remove my foreign ropes, strings, or shoe laces that may be feet to equipment.

▲ WARNING

Il playground equipment and rubber surfacing may become hot enough to cause burns. heck for hot surfaces before allowing childrer to play. Children should wear appropriate shoes at all times.

▲ WARNING

Playing tag or running on or under playgroun equipment can lead to serious injuries from falls, collisions, and head strikes. do not rur on or under playground equipment. Pay attention while playing and be careful.

